Getting started with Sensors

•••

FIONA MCCAWLEY


GITHUB.COM/FIMAC

@SAUCERLIKE


Bosch BME280 - Temperature, Pressure and Humidity sensor




- Equipment
- Setup
- Wiring up the sensor
- Reading from the sensor




Raspberry Pi Zero W




Bosch BME280 sensor



Breadboard



Hammer Header



MicroSD card + Reader








Micro USB Cable


Jumper cables



Soldering setup



Setting up the Raspberry Pi



Elixir & Nerves

Builds a lightweight linux system specifically for a device eg Raspberry
 Pi 3 or Zero.

- Provides a bunch of Elixir modules, including networking and logging.

Provides tooling enabling you to do things like update firmware wirelessly, ssh into a device.

Install Nerves

https://hexdocs.pm/nerves/installation.html



Create new Nerves project and add BMP280 library as a dep

× mix (beam.smp)

TS=64 -pipe -02 -I/Users/fionamccawley/.nerves/artifacts/nerves_system_rpi0-portable-1.14.1/staging/usr/include -std=c99 -D_GNU_SOURCE -o /Users/fionamccawley/projects/nerves/sensor_project/_build/rpi0_dev/lib/muontrap/obj/muontrap.omuontrap.c

/Users/fionamccawley/.nerves/artifacts/nerves_toolchain_armv6_nerves_linux_gnueabihf-darwin_x86_64-1.4 .1/bin/armv6-nerves-linux-gnueabihf-gcc /Users/fionamccawley/projects/nerves/sensor_project/_build/rpi 0_dev/lib/muontrap/obj/muontrap.o --sysroot=/Users/fionamccawley/.nerves/artifacts/nerves_system_rpi0-portable-1.14.1/staging -o /Users/fionamccawley/projects/nerves/sensor_project/_build/rpi0_dev/lib/muontrap/priv/muontrap

if [-f test/Makefile]; then /Applications/Xcode.app/Contents/Developer/usr/bin/make -C test; fi Compiling 5 files (.ex)

Generated muontrap app

==> vintage_net

mkdir -p /Users/fionamccawley/projects/nerves/sensor_project/_build/rpi0_dev/lib/vintage_net/obj
mkdir -p /Users/fionamccawley/projects/nerves/sensor_project/_build/rpi0_dev/lib/vintage_net/priv
/Users/fionamccawley/.nerves/artifacts/nerves_toolchain_armw6_nerves_linux_gnueabihf-darwin_x86_64-1.4
.1/bin/armw6-nerves-linux-gnueabihf-gcc -c -I/Users/fionamccawley/.nerves/artifacts/nerves_system_rpi0
-portable-1.14.1/staging/usr/lib/erlang/erts-11.1.7/include -I/Users/fionamccawley/.nerves/artifacts/nerves_system_rpi0-portable-1.14.1/staging/usr/lib/erlang/lib/erl_interface-4.0.2/include -D_LARGEFILE_
SOURCE -D_LARGEFILE64_SOURCE -D_FILE_OFFSET_BITS=64 -pipe -02 -I/Users/fionamccawley/.nerves/artifact
s/nerves_system_rpi0-portable-1.14.1/staging/usr/include -std=c99 -D_XOPEN_SOURCE=600 -o /Users/fionam
ccawley/projects/nerves/sensor_project/_build/rpi0_dev/lib/vintage_net/obj/to_elixir.o src/to_elixir.c

{:bmp280, "~> 0.2.2"},

Update wifi config

```
config :vintage_net,
  regulatory_domain: "AU",
  config: [
   {"usb0", %{type: VintageNetDirect}},
    {"eth0",
    8{
       type: VintageNetEthernet,
       ipv4: %{method: :dhcp}
     }}.
    {"wlan0",
    %{
       type: VintageNetWiFi,
       vintage_net_wifi: %{
         key_mgmt: String.to_atom(key_mgmt),
         ssid: System.get_env("NERVES_NETWORK_SSID"),
         psk: System.get_env("NERVES_NETWORK_PSK")
       ipv4: %{method: :dhcp}
```

```
firmware > .env

1 export NERVES_NETWORK_SSID=

2 export NERVES_NETWORK_PSK=

3 export MIX_TARGET=rpi0
```

Setup network and usb cable firmware updates

```
..ensor_project (zsh)
  sensor_project mix firmware.gen.script
==> nerves
==> sensor_project
Nerves environment
 MIX_TARGET:
                rpi0
 MIX_ENV:
                dev
Writing upload.sh...
  sensor_project ls
```

Burn to SD card



SSH into device, logging and other tools.




Updating firmware over USB cable or WiFi




Wiring





Start reading temperatures



```
iex(1)> Circuits.I2C.detect_devices
Devices on I2C bus "i2c-1":
 * 119 (0x77)
1 devices detected on 1 I2C buses
iex(2)> {:ok, bmp} = BMP280.start_link(bus_name: "i2c-1", bus_address: 0x77)
{:ok, #PID<0.2050.0>}
iex(3)> BMP280.read(bmp)
{:ok,
 %BMP280.Measurement{
   altitude_m: 67.58225338243035,
   dew_point_c: 15.896116513153766,
   humidity_rh: 60.52678355101699,
   pressure_pa: 99201.45554209204,
   temperature_c: 24.000874632202613
```



Getting started with sensors

Slides: https://github.com/fimac/talks
Repo: https://github.com/fimac/temp_sensor_nerves

GITHUB.COM/FIMAC

@SAUCERLIKE